

SPACELABS Quick Reference Guide

Accessories for: Ultraview



SpO2

| Nellcor OxiSmart | | OEM # | Reorder # |
|------------------|--|-------------|-----------|
| | | 015-0660-00 | S403-010 |
| | | 700-0030-00 | E708-740 |

| Nellcor OxiMax | | OEM # | Reorder # |
|----------------|--|-------------|-----------|
| | | DS-100A | S403-01P0 |
| | | 700-0792-00 | E710-74P0 |

ECG

| Leadwires | | OEM # | Reorder # |
|-----------|--|------------------------------|-----------|
| | | 3 Leads Snap 700-0007-00 | LLB3-90S0 |
| | | 3 Leads Pinch 700-0006-00 | LLB3-90P0 |
| | | 5 Leads Snap 700-0007-08 | LLB5-90S0 |
| | | 5 Leads Pinch 700-0006-10 | LLB5-90P0 |

| Trunk | | OEM # | Reorder # |
|-------|--|------------------------|-----------|
| | | 3 Leads 700-0008-08 | TL-23960 |
| | | 5 Leads 700-0008-06 | TL-25960 |

NIBP

| | OEM # | Reorder # |
|--|-------------|-----------|
| | | F1880S0 |
| | | BP12 |
| | 714-0061-00 | AS-15-150 |

Temp

| | OEM # | Reorder # |
|--|---------------|--------------------------|
| | | DHP-D-20-N0 box of 20 |
| | | DSL-30-PH0 |
| | 20700-4000-00 | DSL-AS0 |